

OPERATING MANUAL



READ THE INSTRUCTIONS CAREFULLY BEFORE OPERATING THIS SLOW JUICER

IMPORTANT SAFEGUARDS

When using an electrical appliance, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS

- 1. To protect against risk of electrical shock, do not put the body (motor) in water or any other liquid.
- 2. Close supervision is necessary when any appliance is used by children.
- Unplug from electrical outlet when not in use and before disassembly for cleaning.
- 4. Avoid contact with moving parts.
- 5. Do not operate appliance with a damaged cord or plug.
- 6. The use of attachments not recommended or sold by the manufacturer may cause damage and will void warranty.
- 7. Do not let cord hang over edge of counter.
- 8. Make sure the motor has stopped completely before dissembling.
- 9. Do not put your fingers or other objects into the juicer while it is in operation. If food becomes lodged in the opening, use the provided food plunger to push it down or press the button into reverse mode. If ingredients are still lodged in the juicing bowls, turn off and disassemble to remove remaining food. You may need to cut produce smaller, or feed ingredients slower into the chute to prevent this.

PARTS AND ACCESSORIES









Fine





Pulp Container



Juice Container



ASSEMBLY INSTRUCTIONS



Step 1: If a silicone cover is not already fitted, place one over spindle as shown.



Step 2: Ensure the yellow pulp at the base of the bowl has been inserted firmly into the outlet. Place the bowl onto the base.



Step 3: Place the desired strainer into the spinning basket and then place these into the bowl, aligning the triangle on the strainer with the triangle on the bowl.



Step 4: Insert auger into strainer/spinning basket. Rotate clockwise until it is sitting firmly in the bowl.



Step 5: Align the open yellow triangles on the hopper and twist the hopper clockwise until the lock position.

OPERATING INSTRUCTIONS

Press the power switch into the ON position. Ensure that the safety switch is unlocked and tap the door to open. Then push your larger round ingredients into the chute allowing it to fall towards the auger. Insert other ingredients into the smaller feeding chute individually. For best results add ingredients at an even, slow pace to ensure maximum extraction is achieved.

CHOOSE YOUR STRAINER

Fine Strainer:

This strainer has small holes to create a fine juice with a small amount of pulp.

Coarse Strainer:

This strainer has larger holes to create a whole-fruit juice (more pulp/ fibre included). The same can be used to make smoothies.

Blank Strainer:

This strainer is blank with no holes to give you the option of making sorbets, nut butters and frozen desserts.

REVERSE FUNCTION

If you notice any ingredients stuck inside the feeder unit use the food pusher to gently push ingredients downwards. The reverse switch is specifically for this reason. Press the reverse switch down for 3-5 seconds and repeat 2-3 times if necessary. Once the auger has come to a complete stop, press the forward switch to continue.

JUICE OUTLET CAP

Close the juice outlet cap to mix your juice inside your juicer. Open the juice outlet cap to dispense as required into the juice container.

CARING FOR THE SILICONE PULP PLUG

It is important to ensure that the pulp plug is always closed before juicing. When you are cleaning the juicing bowl gently unplug the seal and rinse under water.

Replace the seal after cleaning so your juicer is ready to use next time.

SILICONE COVER

Ensure the silicone cover is fitted prior to use. It is another measure to ensure that the motor is sealed from any juice overspill.

Clean after use by removing it from the motor base.

TROUBLE SHOOTING

Problem	Solution
My juicer does not operate when the switch is in the ON position	 Make sure the power cord is properly secured into the power source and that the switch is turned to the 'ON' position. Check that the hopper is assembled correctly. PLEASE NOTE: If the hopper has not been securely locked in place with the arrows aligning, the appliance will not work for safety reasons. This is due to a magnetic safety strip located inside the hopper which must align with the matching magnetic strip inside the base. Check the appliance has been assembled
My juicer has stopped during	according to the instructions in this manual. 1. Reverse/REV to process any fibre that is caught around the auger.
operation	 If your juicer has stopped during operation, please check the alignment of the feeder unit with the base. If the alignment shifts during operation, the juicer will stop.
	 Turn your juicer off, reset the hopper and you should be able to continue.
	PLEASE NOTE: The Slow Juicer has an automatic motor cut off safety feature that will activate if the juicer is overloaded. This has been designed to help prevent accidental damage and to help extend the life of the machine.
	To reset your juicer, take off the hopper lid and remove any ingredients in the juice bowl.

Problem	Solution
The hopper does not open	The hopper opens in an anti-clockwise way. If the hopper does not open easily, try the following:
	 Allow your Slow Juicer to run without ingredients before turning it off and attempting to remove the hopper.
	 Switch your juicer into reverse for a few moments to help dislodge any remaining ingredients around the auger and feeding chute of the hopper.
	PLEASE NOTE: The auger turns in a clockwise direction which is opposite of the hopper. This may cause an unintentional tightening of the hopper and result in difficulty releasing the hopper from the juicing bowl.
	 After you have fed the last ingredients into the hopper, let it run until all the juice and pulp has run through the machine. Pour one or two glasses of water down the hopper to flush out much of the left over pulp. Lift off the entire juicing section before trying to separate.
The bowl shakes when squeezing	A slight shaking of the motor while in operation is completely normal. Variations beyond this depend on the fibre content of the ingredients. Hard or tough ingredients such as carrot and beetroots may cause the bowl to shake more than soft and juicy ingredients.

Problem	Solution
My juice is a little pulpy, how can I fix this?	 Make sure the yellow silicone plug is fully inserted into its slot. This part is removable to assist with cleaning but is often not reinserted correctly. It acts as a pressure point to ensure that the pulp is ejected from the pulp tube.
	2. The outlet can sometimes get blocked if ingredients are fed too quickly into the juicer. Please try slowing down the rate at which you insert produce into the juicer.
	 Try cutting ingredients into smaller pieces (3 to 5cm) so the vertical auger will be able to fully crush and process before the next ingredient is fed in.
	 Fresh and refrigerated ingredients will have firmer fibres and greater water content and will be less pulpy in comparison.
	 Over time, the silicone spinning basket blades may become blunt. Please contact the Customer Care Centre for replacement parts.

FAQS

Do I need to refrigerate fruits and vegetables before juicing them?

Apart from tasting better when juiced, refrigerated fruits and vegetables will provide a higher yield of juice than room temperature produce. This is because the fibre in refrigerated produce is firmer when chilled and consequently provides more juice when crushed compared to softer or warmer fruits and vegetables, which may also be in a partial stage of dehydration (losing water content).

What's the best way to prepare fruits, vegetables and leafy greens for juicing in the Slow Juicer?

VEGETABLES

We recommend preparing your vegetables by cutting them into pieces that will simply fall through the feeding chute without assistance.

FRUITS

We recommend preparing your fruits by cutting them into pieces that will simply fall through the feeding chute without assistance. We recommend removing skins from most citrus fruits although one third of the skin of lemons and limes may be left on.

LEAFY GREENS

Roll leaves into parcels and then fold them in half, ensuring that the parcels will simply fall through the feeding chute without assistance. You may notice with some leafy greens that they can cause the Slow Juicer to clog. This can be remedied by adding a few pieces of carrot or other fibrous vegetables, which will help to push through the leafy greens.

Also, wet leaves will not pass through the juicer as well as drier leaves, so after washing the vegetables pat dry with a kitchen towel before inserting into the Slow Juicer. The vertical crushing and squeezing mechanism of the juicer means that the smaller you cut the pieces before you feed them into the shoot, the less likely that the fibres will become entangled around the internal mechanism. For best results cut your ingredient into 3 to 5 cm pieces.

What can I juice with a Slow Juicer and what should I avoid?

The Slow Juicer can juice just about all types of fruits and vegetables. It is not a food processor so do not place any of the following in the juicer:

- hard coconut fibre soft, young flesh is okay
- seeds
- unsoaked/roasted nuts
- legumes
- sugar cane
- frozen ingredients for sorbet remove fruit from freezer 5-10 minutes before using.
- fish or meat
- liquorice root or other woody materials
- dried herbs and spices
- fruits along with hard seeds
- olives

Can I grind seeds, grains or legumes with the Slow Juicer?

No. The Slow Juicer is not a grinder and using this machine as such may damage the product and void the warranty.

Can the Slow Juicer make cold press oil?

No. This is a different process from juicing and requires different machinery.

Can I make frozen sorbets?

Yes you can easily make frozen fruit sorbets using your juicer.

CLEANING

The Slow Juicer parts are dishwasher-safe (top shelf). For best results, rinse prior to placing into the dishwasher to remove any stubborn fibres.

You can rinse your juicer easily after use by closing the juice outlet cap, and running water through the juicer. Simply open the juice outlet cap to flush the water through.

If hand-washing simply rinse under water, and use the desired cleaning brush to scrub any tough fibres.

We recommend soaking your parts in a solution of bi-carb soda, water and white vinegar or lemon juice after every use. This does a great job of removing any juice stains or residue that may build up over time.

SPECIFICATIONS

Model Type & No.	COLD PRESS SLOW JUICER (SJ01)
Power Supply	230V ∿ 50 Hz
Power Consumption	250 W
RPM	40
Rating	30 MINUTES



COLD PRESS SLOW JUICER - SJ01



SUJATA COLD PRESS SLOW JUICER - SIO1 is warranted against manufacturing defects for a period of two years from the date of purchase. Within this period any defective unit will be repaired or replaced at manufacturer's option, free of cost, subject to the unit being **delivered** to our authorised service centre at customer's cost.

The warranty does not cover damages resulting from commercial use, accident, mishandling or negligence on the part of customer or non compliance of instructions in the operating manual or if the mechanism is tampered with by the customer or any unauthorised person other than our service personnel.

The warranty card duly stamped and signed by the dealer alongwith the cash memo should be produced at the authorised service centre, otherwise the warranty will be treated as invalid. Liability for consequential damages or loss is neither accepted nor implied under the warranty.

PRODUCT WARRANTY REGISTRATION PROCESS

- 1. Save / Click image of purchase invoice in your mobile gallery.
- Scan this QR code for warranty registration or follow the link below https://sujataappliances.com/service-and-support/
- 3. Click on "Register Warranty / Complaint" link.
- 4. Validate Mobile No. with Captcha and OTP as guided on screen.
- 5. Provide / Validate name, Mobile No., Address in required fields and submit.
- 6. Click on "Warranty Registration".
- 7. Provide / Fill all the mandatory fields in the warranty registration form.
- 8. Attach image of purchase invoice from your mobile gallery & submit.
- You will receive a confirmation message on your registered mobile, after completion of product warranty registration process.

SERVICE CALL REGISTRATION PROCESS

- 1. Follow step 2 to step 5 of the warranty registration process.
- 2. Click on "Service Request".
- 3. Provide / Validate all the mandatory details & submit.
- You will receive a confirmation message on your registered mobile once service request is generated.

Model & Serial No.

Bill No. & Date ____

Dealer Stamp with Signature _













Scan for Facebook



Scan for Instagram



Scan for Whatsapp



Version - 1.1

Scan for website







www.sujataappliances.com